


Keyboard Install/Removal Instructions




Using a flat head screw driver insert into the latch holes on keyboard. Press down to eject keyboard.




Lift keyboard. Use flat head screw driver to get “up” if needed. Be careful not to use force here.




A picture before insertion of the keyboard's cable.
(reverse for removal)



A picture after insertion of the keyboard's cable.



Press down on the black latch to secure cable.



Secure the keyboard by pressing firmly around the edges.